Mitsubishi ASX -- SWC Interface

1

LOOP

2

W/R JACK   MIC

Radio
Side

The vehicle may present two different types of steering wheel configuration. In case the steering-wheel controls do not work properly, unplug the two bullet terminals on the loop.

3

4

Car
Connector

5

6

7

8

Front Camera
Connector
(Optional)

Rear Camera
Connector

Ground (Chassis)