2-DIN 12.301260-01



Installation manual for:

Landrover Freelander



Installation kit includes the following items:

- * 1X 2-ISO 110 mm. metal bracket
- * 1X Replacement panel
- * 1X Radio trim
- * 2X Mounting plates
- * 2X Mounting spacers
- * 2X Radio removal keys
- * 4X Screws
- * 2X Cushion





Pioneer HD1BT

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross.
Use position 14 & 16 marked with an arrow.
Measured from left to right.





Pioneer Avic D3

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross. Use position 8 & 10 marked with an arrow Measured from left to right.



2-DIN 12.301260-01

Pioneer sound. vision. soul

1



Car is equipped with original head unit. Remove plastic cover with wedge

3



Remove 4 screws at the location of the arrows. Remove storage bin.

5



Remove 2 screws at the location of the arrows. Remove storage bin.

7



Place plastic frame and metal bracket. Tighten 4 screws at the location of the arrows. Connect all wiring and place head unit

2



Remove 4 screws at the location of the arrows.

4



Remove 2 screws at the location of the arrows. And remove complete compartment.

6



Remove 4 screws at the location of the arrows. Remove Head unit

8



Place panels back in reverse order and place trim ring.