



Installation Manual Double DIN Kit


Standard: 381190-18

Rubber-Touch: 391190-18

- **Mercedes Sprinter (NCV 3) 2006 →**
- **Mercedes Viano / Vito (W639)**
- **Volkswagen Crafter**


Compatible with these Pioneer double DIN devices

Pioneer Navigation




Double DIN Set contents

- (1) Metal Frame
- (2) Installation Kit
- (3) Facia Plate
- (4) Trim Frame



(sample photo)



(sample photo)

Mount the metal brackets to the double DIN head unit.

The position of the copper coloured holder can be adjusted to your needs for perfect fit. (see sample)



5. Place the fascia plate on the dashboard. Fix it with the four original screws.

Push the Metal Frame into the fascia plate.

Connect all required circuit points and push the double DIN head unit in the metal frame until it snaps in.

Place the trim frame.

Reinstall everything in reverse order to finish installation.

Mercedes Viano / Vito (W639)



1. Vehicle with OEM head unit.


Remove the trim panel surrounding the radio.



2. Remove the four screws at the top and bottom of OEM head unit.




3. Remove the OEM head unit.



(sample photo)

Mount the metal brackets to the double DIN head unit.



(sample photo)

The position of the copper coloured holder can be adjusted to your needs for perfect fit. (see sample)



4. Place the fascia plate on the dashboard. Fix it with the four original screws.

Push the Metal Frame into the fascia plate.

Connect all required circuit points and push the double DIN head unit in the metal frame until it snaps in.

Place the trim frame.

Reinstall everything in reverse order to finish installation.