



Cut off and put
RCA plug on in
Order to use with
Avic-F950BT

Connect to the purple
wire of the interface
and/or unit's
powercable

Connect to the car side

Put in to the back of
the Avic unit where
the microphone should
go