

2014 or NEWER Harley-Davidson®

M5-800X4 Amplifier Tuning

HD14-SBSUB Saddlebag Subwoofer Kit



MOTORCYCLE AUDIO

#ROCKFORDFOSGATE



Boom!™Box
Standard 4.3



Boom!™Box
Premium 6.5GT



Boom!™Box
Premium GTS



RADIO FLASH REQUIRED

"Rockford Fosgate Tune 2014+ All Models"

REMOTE TURN-ON REQUIRED

use turn-on from brake side

REAR INPUT LEVEL: 02:00

Matches amplifier input to radio's output. Tells amp where to "clip."

FRONT INPUT LEVEL: 02:00

Matches amplifier input to radio's output. Tells amp where to "clip."

PUNCH EQ: MIN

Used to compensate for acoustical deficiencies in automotive interiors. Not used on motorcycles.

INPUT SWITCH: 2CH

Number of inputs to feed amplifier. Set to require only 2 inputs to feed all 4 amplifier channels.

CROSSOVER FREQUENCY: 80Hz

The crossover's cutoff frequency. Set to allow only low frequencies to pass to subwoofers (works with HP/AP/LP switch.)

PRESET SWITCH: OFF

Used only for Motorsport (SXS) setups. Not used on motorcycles.

CROSSOVER SWITCH: LP (Low-Pass)

Allows crossover to work in High-Pass, Low-Pass or All-Pass (bypass). Set to allow only low frequencies to pass to subwoofers (works with crossover frequency dial.)

