

USB and Jack 3,5mm replacement PCB installation kit for:

JEEP

Model: Renegade

Year: 2015>

Kit content: USB and Jack 3,5mm replacement PCB

Customer code:





1 This is how the original dashboard looks like. Some plastic parts need to be removed and used with the new interface.



2 Remove this plastic part from the dashboard.



3 Take the original part and, in order to unhook the rear plastic, use a screw driver to carefully push the four holes indicated in the picture with circles and arrows.



4 Open the clips and remove the original component as shown in the picture.



5 Save this piece from the original component and mount it, in the same location, on to the supplied component.



6 Disconnect the harness from the supplied PCB. Insert the PCB into the plastic part in the right position as shown. Plug back in the harness that you previously disconnected.



7 Insert the component as shown in the picture. Plug all connections on radio side. Insert the USB and Jack 3,5mm replacement panel into the hole left by the OEM part.