

USB and Jack 3,5mm replacement PCB installation kit for:

# KIA

Model: Sportage; Ceed;

Year: 2016>

Kit content: USB and Jack 3,5mm replacement PCB

Customer code: CA-IW-KM.006VR



## INSTALLATION MANUAL

All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
01/2018 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.R3

All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
01/2018 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

## SPORTAGE

1) Take out the OEM interface and unplug the connector.



## CEED



2) Remove the front plastic cover by pushing the lateral hooks and remove the original PCB.



**Save** the white plastic after removing the PCB.

3) Place the new PCB into the white plastic and then place the whole part into the rear black cover.



**Don't save** the transparent plastic after removing the PCB.

Place the new PCB, without the transparent plastic, into the rear black cover.



## SPORTAGE

4) Put in place and fix the front plastic cover.



## CEED



5) Take the supplied harness and plug in the connector. Connect the 3.5mm Jack and the USB plugs to the head unit. Connect the **Black wire to the GND** and the **Orange wire to ACC +15 signal wire or head lights signal wire** (picture 5A). Check the proper functioning of the system and the illumination. Remount the interface on the dashboard.



**NOTE:** If the car is equipped with original navigation, the rear plastic of the interface has two windows for the connections, in order to fit the connector of the supplied cable you must cut and remove the two plastic piece as shown in the picture (cut along the dotted line).

