



**BW8**

8" BMW Specific Subwoofer

User's Manual

# INSTALLATION

Needed tools for installation:

- Blade screwdriver
- Ratchet with T50 Torx
- Torx screwdriver T10,T15,T20,T25
- #2 Phillips screwdriver

Manual reference is a BMW F10/11. Other vehicles may differ depending on model, year and options

## 1 - Seat Removal

Remove the bolts that hold the seat track to the floor.

Once all of the bolts are removed, tilt the seat back to provide access to the subwoofer.

## Warning

Do not unplug the wires under the seat. Doing so could generate an Airbag failure and require the BMW-Service to get cleared. As a precaution it is advisable to disconnect the vehicle's battery before installation (see owner's manual of your car for further information).

## 2 - Subwoofer grill removal

Remove plastic cover to expose subwoofer.

## 3 - Subwoofer removal

Remove the screws that hold the subwoofer. Lift the subwoofer out of the housing and unplug the factory harness connector.

## 4 – Subwoofer installation

Plug factory harness into the **awave BW8**. Place the new subwoofer into the original housing and use same factory screws to mount it.

## 5 – Reinstall subwoofer grill

Install the subwoofer plastic cover using the factory screws.

## 6 – Reinstall seat

Mount the seat back down onto the floor. Tighten the original bolts carefully with factory specs.

## SPECIFICATIONS

<b>Model</b>	<b>BW8</b>
Impedance	20ohm
Frequency response	35-250Hz
RMS Power	100W
Max Power	200W
RE	1.80hm
SPL	88dB
FS	55Hz
QMS	5.57
QES	1.5
QTS	1.18
VAS	15.98L/0.56 cu.ft
MMS	41.58Gr
BL	4.4 N/A
RMS	2.77kg/s
CMS	0.17mm/N
LE	0.35mH