



**HIGH PERFORMANCE
STAINLESS STEEL EXHAUSTS**

SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.1190.00 / 58.1191.00**

REV. **00**

DEL. **22/07/2026**

TEC-LOG **G.D.**

Descrizione **BMW F40**

Fig. 1

-  Tagliare lo scarico originale.
-  Cut the original exhaust.
-  Coupez l'échappement d'origine.
-  Corta el escape original.
-  Den Originalauspuff abschneiden.



Fig. 2

-  Fissare la staffa in dotazione come in foto ed agganciare lo scarico utilizzando il gommino!
-  Fix the brackets in equipment as shown in the photo and hook the exhaust by using the gum-ring;
-  Fixer l'étrier en dotation comme indiqué sur la photo et en utilisant le petit bouchon en caoutchouc accrocher l'échappement!
-  Fijar el estribo en dotación como se muestra en la foto y enganchar el escape utilizando el anillo de goma!
-  Fixieren Sie die Schelle des Montagekits wie auf dem Foto gezeigt und setzen Sie die Anlage mit Hilfe des Gummirings ein!



Fig. 3

