


HARD WIRED REMOTE CONTROL INTERFACE
Adaptateur commande au volant / Stuurafstandsbediening / Lenkradbedienung



Honda
Civic Hatchback 2006>




Tools/Outils/Gereedschap/Werkzeug:



Phillips

1. Blue Wire (Bleu) - Amplifier Remote (Extérieur d'amplificateur)


Autoradio:



lock	Front view
	ISO power connector: 2 4 6 8
	1 3 5 7

- A1 = Speed Signal - Blue/Black Wire**
Impulsion de Vitesse - Bleu/Noir
- A2 = Reverse Gear - Purple Wire**
Marche arrière - Violet
- A3 = Not Connected**
Non relié
- A4 = +12 Volts - Yellow Wire**
+12 Volts - Jaune
- A5 = Antenna Remote**
Extérieur d'antenne
- A6 = Illumination - Orange Wire**
Illumination - Orange
- A7 = Ignition - Red Wire**
Ignition - Rouge
- A8 = Ground - Brown Wire**
La terre - Brun

Navigation:



User Guide

Setting the Clock and Date

1. Press and hold 'MODE' to enter clock setting mode
2. Press VOL + and VOL - to toggle between hour, minute, date, month and year. The relevant character will flash when selected
3. To change the value, press CH + and CH-
4. Once the time and date has been set, press and hold 'MODE' to exit clock setting mode.

